

User Manual **Dynamic Load Compensation** JOFRA DLC-155/158/159/250/700

...because calibration is a matter of confidence











User manual JOFRA DLC-155/158/159/250/700

© Copyright 2012 AMETEK Denmark A/S



Table of contents:

1.0	General information4			
2.0	Introduction5			
3.0	Functionality			
	3.1	Functional description	6	
	3.2	Connections	7	
	3.3	Serial number	8	
4.0	Operation			
	4.1	Operation area	9	
5.0	Mai	ntenance	10	
	5.1	Calibration	11	
6.0	Тес	hnical specifications	17	

Page

1.0 General information

This manual is only effective for the following products:

JOFRA DLC-155 JOFRA DLC-158 JOFRA DLC-159 JOFRA DLC-250 JOFRA DLC-700

The products are manufactured by:



AMETEK Denmark A/S Gydevang 32-34 3450 Allerød - Denmark

TEL: +45 48 16 80 00 FAX: +45 48 16 80 80

2.0 Introduction

The JOFRA DLC-155, DLC-158, DLC-159, DLC-250 and DLC-700 probes are designed for fast and traceable calibration and temperature measuring with JOFRA RTC-156/157 B/C, JOFRA RTC-158 B/C, JOFRA RTC-159 B/C, JOFRA RTC-250 B/C and JOFRA RTC-700 B/C systems and are ready for use.

Please read this manual carefully before use, to obtain maximum value of your calibration system.



Warning

- Read this manual before use.
- Do not use in hazardous area.
- Handle carefully.
- Never exceed temperature range

3.0 Functionality

3.1 Functional description

The probes can be used for temperatures in the range :

- DLC-155 : -60°C to 155°C / -76°F to 311°F
- DLC-158 : -60°C to 155°C / -76°F to 311°F
- DLC-159 : -100°C to 155°C / -148°F to 311°F
- DLC-250 : 0°C to 250°C / 32°F to 482°F
- DLC-700 : 0°C to 700°C / 32°F to 1292°F

The JOFRA DLC-155, DLC-158, DLC-159, DLC-250 and DLC-700 probes may be supplied with a certificate for a limited temperature range. The calibration temperature ranges for the DLC sensors are stated on page 19.

3.2 Connections

The probes are delivered with a connecting cable. The pin-layout is as follows:

Pin 1 : TC V-Pin 2 : TC V+ Pin 3 : Memory GND Pin 4 : Memory I/O

The figure below is shown from the connector side of the probe connector.



3.3 Serial number

The serial number is placed on the probe as shown on the figure below:



4.0 Operation

4.1 Operation area

All the probes are intended for use in areas which meet the following:

Ambient temperature

range	:	-20°C to 70°C (-4°F to 158°F)
Humidity	:	0% to 90%

Protection class : IP 50



Warning

Do not use in hazardous areas.

5.0 Maintenance

The probe does not require specific maintenance before or after use. The user may carry out the following procedure himself:

• Cleaning the probe : Use alcohol or water and a soft cloth.



Caution...

- The probe must always be protected against any mechanical damage.
- The probe must never be exposed to mechanical shock effects.
- Avoid thermal shock
- Any bending of the probe may cause permanent damage

5.1 Calibration

Required equipment:

- DLC-probe to be calibrated.
- RTC-calibrator with DLC-input.
- An insert with correct size holes for the DLCprobe and the temperature probe.
- For calibrating DLC-155, DLC-158, DLC-159 and DLC-250: an AMETEK 127587 temperature probe (recommended) or similar with short measuring zone is required.
- For calibrating DLC-700: a STS-200 A 970 temperature probe (recommended) or similar is required.

Calibration setup:

Sensor	DLC-155	DLC-155	DLC-700
Calibrator	RTC-156	RTC-157	RTC-700
Insert*	127312	127312	127149
Temp. probe*	127587	127587	STS-200 A
			970
EXCEL	127588	127588	127589 DLC-
spreadsheet**	DLC-	DLC-	700.XLS
•	155.XLS	155.XLS	
Recommended	-30°C/-22°F	-45°C/-49°F	33°C/91.4°F
calibration	-20°C/-4°F	-20°C/-4°F	200°C/392°F
temperatures***	0°C/32°F	0°C/32°F	350°C/662°F
	50°C/122°F	50°C/122°F	500°C/932°F
	100°C/212°F	100°C/212°F	660°C/1220°F
	155°C/311°F	155°C/311°F	700°C/1292°F
Lower	Bottom of	Bottom of	Bottom of
measuring point	insert	insert	insert
Upper	60 mm /	60 mm /	80 mm / 3.1"
measuring point	2.4" from	2.4" from	from bottom
	bottom	bottom	
Curve fit	0.01°C/	0.01°C /	0.05°C /
warning limit	0.018°F	0.018°F	0.09°F

Sensor	DLC-158	DLC-250	
Calibrator	RTC-158	RTC-250	
Insert*	124897	127759	
Temp. probe*	127587	127587	
EXCEL	127884 DLC-	127885 DLC-	
spreadsheet**	158.XLS	250.XLS	
Recommended	-22°C/-72°F	28°C/82°F	
calibration	-10°C/-4°F	50°C/122°F	
temperatures ***	0°C/32°F	100°C/212°F	
	50°C/122°F	150°C/302°F	
	100°C/212°F	200°C/392°F	
	155°C/311°F	250°C/482°F	
Lower	Bottom of insert	Bottom of insert	
measuring point			
Upper	60 mm / 2.4" from	60 mm / 2.4" from	
measuring point	bottom	bottom	
Curve fit	0.01°C/ 0.018°F	0.01°C / 0.018°F	
warning limit			

Sensor	DLC-159
Calibrator	RTC-159
Insert*	128477
Temp. probe*	127587
EXCEL	128583 DLC-
spreadsheet**	159.XLS
Recommended	-100°C/-148°F
calibration	-50°C/-58°F
temperatures ***	0°C/32°F
	50°C/122°F
	100°C/212°F
	155°C/311°F
Lower	Bottom of insert
measuring point	
Upper	60 mm / 2.4" from
measuring point	bottom
Curve fit	0.01°C/ 0.018°F
warning limit	

* Recommended equipment.

** EXCEL spreadsheet is found on the USB-stick with JOFRACAL.

*** The temperatures must be entered in Celcius.

Procedure:

- 1. Place the DLC-probe in the insert and connect the probe to the DLC-input of the calibrator.
- 2. Go to the "Sensor setup" menu.
- Set "Use load compensation" to "YES". If the reference probe is connected to the "REF" input, set "Sensor type" to "External" and "SET follows TRUE" to "No". If no reference probe is connected, set "Sensor type" to "Internal".
- 4. Enter the DLC-menu.
- 5. Read the A, B and C-coefficients of the probe and enter the values in the EXCEL spreadsheet.

Series Series Series Series Control of the series Management Series	resoll Lacel - 1275 Arr Packar Vic 1	Ideal Formater Functioner	Data Wolke Hield			Selvent spare	a los	
Step 3 Step 4 Step 4 Contraction of DLC-155 sensor Step 4 Step 3 Step 4 Contraction of DLC-155 sensor Step 3 Step 4			Line No. 10 To	A11.00 1000		and the Area A		
Series No. Series		01 1 11 N 11 10 . V	1.1	The second second	Store and			
Calibration of DLC-155 sensor Senal No 120406-1736 Senal No SEp 2 Immediate Sattemperature Notation DLC Data No and No No No No <th colsp<="" th=""><th></th><th>all sealing the seal of the later</th><th>and Bud sides. Make the</th><th>Carlot and</th><th></th><th></th><th></th></th>	<th></th> <th>all sealing the seal of the later</th> <th>and Bud sides. Make the</th> <th>Carlot and</th> <th></th> <th></th> <th></th>		all sealing the seal of the later	and Bud sides. Make the	Carlot and			
Calibration of DLC-155 sensor Sensitive 12369-1236 Step 1 Step 2 Conflocent Curron value Step 2 2 -230,000 -20,000 2 -230,000 50,000 0,000 4 50,000 50,000 0,000 4 50,000 50,000 0,000 5 100,000 150,000 155,000 155,000 8 1,00000000000 -2 -230,000 50,000 0,0000 4 50,000 150,000 155,000 155,000 0,0000 5 100,000000000 1 -300,000 0,0000 0,0000 6 155,000 0,00000 3 0,0000 0,0000 3 0,0000 0,0000 3 0,0000 0,0000 3 0,0000 0,0000 3 0,0000 0,0000 3 0,0000 0,0000 3 0,0000 3 0,0000 0,0000 3 0,0000 3 0,0000 0,0000								
Senal No. 12456-1246 Step 1 Step 2 Continuent Current value Temperature Set temperature Measured value Dic reactive 0 0.000000E+00 0 0.00000E+00 0.00000E+00 0.00000E+00 0.000000E+00 0.00000E+00 0.000000E+00 0.00000E+00 0.0		Calibra	tion of DLC	C-155 sense	or			
Step 1 Step 2 Control value Control value Cl control value		Senal No. 123	456-12345					
Step 3 Step 4 Constraint Constraint Discover A 50,0000 50,000 0,000 B 1,000000E+00 0,000 0,000 0,000 0,000 Constraint 0,00000E+00 0,000	Step 1		Step 2	0				
B 1,000000E-00 1 -30,000 -30,000 -30,000 -30,000 0,000	Coefficient	Current value 0.000000E+001	Temperature	Set temperature	Measured value	Measured value	DLC readin	
C 0.00000E-00 2 -20,000 -20,000 0.000 0.000 3 0.000	В	1,000000E+00	1	-30,000	-30,000	-30,000	0.00E+0	
3 0,000 3 0,000 0,0000 3 0,000 0,0000 5 10,0000 0,0000 5 10,0000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 6 155,000 0,0000 10 10 10 10 10 10 10 10 <t< td=""><td>C</td><td>0,000000E+00</td><td>2</td><td>+20,000</td><td>-20,000</td><td>-20,000</td><td>0,00E+0</td></t<>	C	0,000000E+00	2	+20,000	-20,000	-20,000	0,00E+0	
Step 3 Step 4 Control of the state of t	11-20-	and the second sec	3	0,000	0,000	0,000	0,00E+0	
Step 3 Step 4 Coefficient Newcommerciant Convolt 0,0000 B 1,000000 = 000 C 0,000000 = 000 C 0,000000 = 000 C 0,000000 = 000 C 0,000000 = 000 3 0,0000 5 100,0000 6 155,000 6 155,000			- 4	50,000	50,000	50,000	0,00E+0	
Step 3 Step 4 Conflictent New value Temperature Calculated A 0.00000000000000000000000000000000000			5	100,000	100,000	100,000	0,00E+0	
Step 3 Step 4 Conficient Amountain of the second and the second a			6	155,000	155,000	155,000	0,00E+0	
Control Ferroristative Cascuded B 1,00000E+00 1 -35,000 0,00000 C 0,00000E+00 2 -23,000 0,0000 3 0,000 0,0000 5 10,0000 5 10,000 0,0000 6 15,000 0,0000	Step 3		Step 4					
A 0.000006-00 389p temperature Curve in B 1.000006-00 1 -33000 0.00000 C 0.000006-00 2 -30000 0.0000 3 0.0000 0.0000 4 50000 0.0000 5 100.000 6 155.000 0.0000	Coefficient	New value	Temperature	Tomorreture	Calculated			
C 0.000000E+000 2 -0.0000 0.0000 3 0.000 0.0000 4 50.000 0.0000 4 50.000 0.0000 6 155.000 0.0000	P	1.000000E+00	Stop	30,000	0.0000			
	6	0.000000E+00	2	-30,000	0,0000			
4 50,000 0,0000 5 100,000 0,0000 6 155,000 0,0000	6	0,000000E+00		-20,000	0,0000			
7 00000 00000 6 155,000 0,0000			0	50,000	0,0000	1.1.1		
6 155,000 0,0000			5	100,000	0,0000	Carlo and		
133,000 0,0000			6	155,000	0,0000			
			0	132,000	0,0000	the Design of the		

The following procedure is repeated for each temperature:

- 1. Set the SET temperature.
- Place the reference temperature probe in the bottom of the insert.
 Wait until the temperature have stabilized and the DLC-reading is 0.00°C. If the DLC-reading continuously shows a positive value at -30°C (RTC-156) / -45°C (RTC-157) / -22°C (RTC-158) / -100°C (RTC-159), increase the SETtemperature in steps of 1°C until the DLC-reading displays 0.00°C.
- 3. Record the temperature of the reference probe in the excel spreadsheet.
- 4. Move the reference probe to the upper position 60 mm (RTC-156/157/158/159/250) or 80 mm (RTC-700).
- 5. Wait until the temperature have stabilized and the DLC-reading is 0.00°C.
- 6. Record the temperature of the reference probe and the DLC-probe in the excel spreadsheet.
- 7. Go to next SET-temperature.

After the last STEP is completed:

 Check that all values in the calculated curve fit are less than the values specified in the table. If this is OK, the new coefficients can be downloaded using the CON050 software.

6.0 Technical specifications

Probe specifications - DLC-155:

Sensor type	:	Differential TC type T
Probe length	:	177 mm (6.96 in)
Temperature range	:	-60°C to 155°C / -76°F to 311°F
Diameter	:	OD3 mm
Depth	:	140 mm (5.51 in)
Media compatibility	:	AISI316
Connection	:	Redel plug with build in memory is standard

Probe specifications - DLC-158:

Sensor type	:	Differential TC type T
Probe length	:	196 mm (7.72 in)
Temperature range		-60°C to 155°C / -76°F to 311°F
Diameter	:	OD3 mm
Depth	:	140 mm (5.51 in)
Media compatibility	:	AISI316
Connection	:	Redel plug with build in memory is standard

127414	03	2012-11-12

Probe specifications - DLC-159:

Sensor type	:	Differential TC type T
Probe length	:	196 mm (7.72 in)
Temperature range	:	-100°C to 155°C / -148°F to 311°F
Diameter	:	OD3 mm
Depth	:	140 mm (5.51 in)
Media compatibility	:	AISI316
Connection	:	Redel plug with build in memory is standard
Probe specifications	- I	<u>DLC-250:</u>
Sensor type	:	Differential TC type T
Probe length	:	196 mm (7.72 in)
Temperature range	:	0°C to 250°C / 32°F to 482°F
Diameter	:	OD3 mm
Depth	:	140 mm (5.51 in)
Media compatibility	:	AISI316
Connection	:	Redel plug with build in memory is standard

Probe specifications - DLC-700:

Sensor type		Differential TC type N
Probe length		230 mm (9,05 in)
Temperature range	:	0°C to 700°C / 32°F to 1292°F
Diameter	:	OD4 mm
Depth	:	200 mm (7.9 in)
Media compatibility	:	INCONEL 600
Connection	:	Redel plug with build in memory is standard

Certificate:

If the DLC probes are supplied with a certificate, the calibration is carried out as recommended below according to the ITS 90 temperature scale.

The DLC-155/158 probe is as standard calibrated in the range :

```
-45°C to 155°C (-49°F to 311°F).
```

The DLC-159 probe is as standard calibrated in the range :

```
-100°C to 155°C (-148°F to 311°F).
```

The DLC-250 probe is as standard calibrated in the range :

```
28°C to 250°C (82°F to 482°F).
```

The DLC-700 probe is as standard calibrated in the range :

33°C to 700°C (91.4°F to 1292°F).

AMETEK Calibration Instruments

is one of the world's leading manufacturers and developers of calibration instruments for temperature, pressure and process signals as well as for temperature sensors both from a commercial and a technological point of view.

JOFRA Temperature Instruments

Portable precision thermometers. Dry-block and liquid bath calibrators: 5 series, with more than 25 models and temperature ranges from -90° to 1205°C / -130° to 2200°F. All featuring speed, portability, accuracy and advanced documenting functions with JOFRACAL calibration software.

JOFRA Pressure Instruments

Convenient electronic systems ranging from -25 mbar to 1000 bar (0.4 to 15,000 psi) - multiple choices of pressure ranges, pumps and accuracies, fully temperaturecompensated for problem-free and accurate field use.

JOFRA Signal Instruments

Process signal measurement and simulation for easy control loop calibration and measurement tasks - from handheld field instruments to laboratory reference level bench top instruments.

JOFRA / JF Marine Instruments

A complete range of calibration equipment for temperature, pressure and signal, approved for marine use.

FP Temperature Sensors

A complete range of temperature sensors for industrial and marine use.

M&G Pressure Testers

Pneumatic floating-ball or hydraulic piston dead weight testers with accuracies to 0.015% of reading.

M&G Pumps

Pressure generators from small pneumatic "bicycle" style pumps to hydraulic pumps generating up to 1,000 bar (15,000 psi).



TEST & CALIBRATION INSTRUMENTS

UK AMETEK Calibration Instruments Tel +44 (0)1243 833 302 jofra@ametek.co.uk

France AMETEK S.A.S. Tel +33 (0)1 30 68 89 40 general.lloyd-instruments@ametek.fr

Germany AMETEK GmbH Tel +49 (0)2159 9136 510 info.mct-de@ametek.de Denmark AMETEK Denmark

Tel +45 4816 8000 jofra@ametek.com

USA

AMETEK Mansfield & Green Tel +1 (800) 527 9999 cal.info@ametek.com

India

AMETEK Instruments India Pvt Ltd. Tel +91 22 2836 4750 jofra@ametek.com

www.jofra.com

Singapore

AMETEK Singapore Pte Ltd Tel +65 6484 2388 jofra@ametek.com

China AMETEK Inc. - Shanghai Tel +86 21 5868 5111

AMETEK Inc. - Beijing Tel +86 10 8526 2111

AMETEK Inc. - Guangzhou Tel +86 20 8363 4768 jofra.sales@ametek.com.cn

Information in this document is subject to change without notice. ©2012 by AMETEK, Inc., www.ametek.com. All rights reserved.