

User Manual JOFRA STS-100 A/B

©Copyright 2010 AMETEK Denmark A/S

...because calibration is a matter of confidence











User manual JOFRA STS-100 A/B Probes 250/350/500/901

© Copyright 2010 AMETEK Denmark A/S



1.0	General information4					
2.0	Safe	Safety instructions5				
3.0	Introduction7					
4.0	0 Functionality					
	4.1	Functional description	8			
	4.2	Connections	8			
	4.3	Serial number	10			
5.0	Оре	eration	11			
	5.1	Operation area	11			
6.0	Mai	Maintenance12				
7.0	Тес	chnical specifications	13			

This manual is only effective for the following products:

JOFRA STS-100 A/B - 250 mm

JOFRA STS-100 A/B - 350 mm

JOFRA STS-100 A/B - 500 mm

JOFRA STS-100 A/B - 901 (90°)

The products are manufactured by:



AMETEK Denmark A/S Gydevang 32-34 3450 Allerød - Denmark

> TEL: +45 48 16 80 00 FAX: +45 48 16 80 80



Read this manual carefully before using the sensor!

In order to avoid any personal injuries and/or damage to the sensor all safety instructions and warnings must be observed.



Warning

- Do not use in hazardous area.
- Handle carefully.
- Never exceed temperature range



Caution...

- When measuring temperature in fluids (e.g. at re-calibration) the enclosed protection tube must be used.
- The probe must **always** be protected against any mechanical damage.
- The probe must **never** be exposed to mechanical shock effects.

- Avoid thermal shock
- Any bending of the probe may cause permanent damage
- **Never** use power or tools to place the probe.

3.0 Introduction

The JOFRA STS-100 A/B probes are specially designed for fast and traceable calibration and temperature measuring with your JOFRA equipment, and are ready for use.

Please read this manual carefully before use, to obtain maximum value of your calibration system.



Warning

- Read this manual before use.
- Do not use in hazardous area.
- Handle carefully.
- Never exceed temperature range

4.1 Functional description


The sensor can be used for measuring temperature in the range -150°C to 650°C (-238°F to 1202°F).

The STS-100 A/B probes may be supplied with certificates for a limited temperature range.

The resistance of the JOFRA STS-100 A/B probe is converted to temperature according to IEC-751 (ITS-90) (calculated coefficients for the probe specific are stated on the certificate).

4.2 Connections


The probe is delivered with a connecting cable and with the following options:




Model with banana plugs: 2 meter cable

Use the ground terminal in order to reduce noise.

Model with Lemo connection: 2 meter or 0.5 meter cable




Model with Redel/Lemo connection: 2 meter cable



4.3 Serial number

The serial number is placed on the connector as shown on the figure below:



5.1 Operation area

All the probes are intended for use in areas, which meet the following operating conditions:

Probe connector							
and cable	:	-20°C to 70°C (-4°F to 158°F)					
Storage temp.	:	-20°C to 70°C (-4°F to 158°F)					
Humidity	:	0% to 90% RH					
Protection class	:	IP 50					



Warning

Do not use in hazardous areas.

6.0 Maintenance

The probe does not require specific maintenance before or after use. The user may carry out the following procedure himself:

Cleaning sensor : Use alcohol or water and a soft cloth.



Caution...

- The probe must **always** be protected against any mechanical damage.
- The probe must **never** be exposed to mechanical shock effects.
- Avoid thermal shock
- Any bending of the probe may cause permanent damage

7.0 Technical	sp	ecifications
Sensor type		Platinum sensor Pt100. $\alpha = 0.00385$
Probe length		250 mm 350 mm 500 mm 165 mm (90° Angle)
Temperature range		-150°C to 650°C (-238°F to 1202°F)
Accuracy		,
Repeatability	:	0.002°C
Hysteresis ¹⁾	:	0.01°C @ 0°C
Stability ²⁾	:	typ. 0.014°C @ 0°C
Self heating effect		0.06°C/mW
Diameter	:	A: OD4 mm B: OD1/4"
Immersion depth		A: 100 mm B: 110 mm
Media compatibility		INCONEL 600

- -

1)When used in the range -90° C to 650° C (-130°F to 1202° F) 2)Stability when exposed to 650° C (1205° F) for 100 hours. Stability will depend on actual use of the sensor.

Response time	:	A: $\tau(50\%) = 8$ sec. $\tau(90\%) = 26$ sec.
		B: $\tau(50\%) = 18$ sec.
		$\tau(90\%) = 44$ sec.
Recommended		
meas. current	:	1 mA
Connections	:	Lemo plugs are standard

Certificate:

If the STS-100 A/B reference probe is supplied with a certificate, the calibration is carried out as recommended below according to the ITS 90 temperature scale. The STS-100 A/B type H/F probe is as standard calibrated in the range : -45°C to 650°C (-49°F to 1202°F) The STS-100 A/B type HL/FL probe is as standard calibrated in the range : -90°C to 125°C (-130°F to 257°F).

It is recommended to calibrate in minimum 3-6 calibration points (depending on the temperature range) above 0°C and in minimum 2 calibration points beneath 0°C.



AMETEK

Calibration Instruments

One of the world's leading manufacturers and developers of calibration instruments for temperature, pressure and process signals as well as for temperature sensors both from a commercial and a technological point of view.

www.jofra.com



AMETEK Denmark A/S Gydevang 32-34 • 3450 Allerød • Denmark Tel: +45 4816 8000 • ametek@ametek.dk

Sales & Service: Europe, Asia, Africa, Middle East and South America

Information in this document is subject to change without notice. ©2010, by AMETEK, Inc., www.ametek.com. All rights reserved. AMETEK Mansfield & Green (North America) Tel: +1 800 527 9999 • cal.info@ametek.com

AMETEK Singapore Pte. Ltd. (Singapore) Tel: +65 6 484 2388 • aspl@ametek.com.sg

AMETEK Inc. Beijing Rep. Office (China) Tel: +86 10 8526 2111 • jofra@ametek.com.cn

AMETEK GmbH (Germany) Tel: +49 2159 9136 510 • info.mct-de@ametek.de

AMETEK Calibration Instruments (UK) Tel: +44 (0) 1243 833 302 • jofra@ametek.co.uk